



Spoken Tutorial, IIT Bombay

<https://spoken-tutorial.org/>

eSim

Subcircuit Builder in eSim - Assignment

1. Create a subcircuit of Full Adder using Subcircuit Builder in eSim. The Full Adder component symbol (Part Library) should have only four pins : A, B, C and Sum. No carry pin is required.

Hint: Dont connect Port E. Replace with a 'No connect' symbol.